HOW TO USE ACIDIC MILK LINE FROTHER CLEANER

For Soaking Parts

- Remove parts & place in a soaking container
- Add very hot water to container to cover parts
- Dilute 25-50ml of concentrate into the water to create a solution
- Leave parts to soak for 20-30 minutes
- Rinse parts thoroughly with warm water before re-assembly

For Automatic Milk Line Circuits

- Dilute 25-50ml concentrate per 1 litre of cold water in a container
- Insert suction tube into the solution & place empty container under milk spout
- Run the solution through the entire milk line circuit
- Flush circuit with clean cold water to ensure components are thoroughly rinsed before use



