## HOW TO USE COFFEE MACHINE CLEANER

## For Traditional Cappuccino Machines

- Place blank filter into holder & add up to 25ml (3 capfuls)
- Insert holder into group
- Switch on group & backwash for at least 30 seconds
- Discharge waste water & repeat until water runs clear
- Rinse thoroughly with warm water to finish

## For Automatic Machines

- Pour up to 25ml (3 capfuls) into brewer chamber
- Switch to hot water cycle & flush for 5-10 minutes
- After automatic draining, switch to brewer flush to rinse system thoroughly to finish



